

## Table of Contents

### FT100 M

<b>Chapter 1 Introduction</b>	
GENERAL .....	1-1
PHYSICAL DESCRIPTION .....	1-1
Front Panel .....	1-2
Rear Panel .....	1-3
FEATURES .....	1-3
<b>Chapter 2 Installation and Startup</b>	
GENERAL .....	2-1
RECEIPT INSPECTION .....	2-1
SITE PREPARATION .....	2-2
CONNECTIONS .....	2-2
MGT Connections .....	2-2
Network Connections .....	2-2
Port Connections .....	2-4
V.35/RS-449 Adapter Installation .....	2-5
HARDWARE OPTIONS .....	2-5
<b>Chapter 3 Configuration Management Card</b>	
GENERAL .....	3-1
DIP SWITCHES .....	3-2
Speed .....	3-2
Parity .....	3-2
Stop Bit .....	3-2
Character Length .....	3-2
Flow Control .....	3-2
TERMINAL/MODEM INTERFACE STRAP .....	3-4
Chassis Ground to Digital Ground Connection .....	3-5
ALARM / SENSE TERMINAL BLOCK .....	3-6
TERMINAL SCREEN OPERATION .....	3-6
System Screen .....	3-7
Banner Region .....	3-8
Menu Region .....	3-8
Parameter Region .....	3-8
Options Region .....	3-9

*Table of Contents*

---

<Config> .....	3-10
Reset .....	3-10
<Utility> .....	3-10
Address/ID .....	3-10
Time/Date .....	3-11
Terminal .....	3-12
Password .....	3-12
<System> .....	3-14
<Alarm> .....	3-14
Alarm History .....	3-14
Dest(ination) 1, 2, 3 .....	3-15
<b>Chapter 4 T1 Interface Card</b>	
GENERAL .....	4-1
DTE INTERFACE OPTIONS .....	4-1
Installing an Interface Card .....	4-1
Using a Conversion Adapter .....	4-3
SOFTWARE CONFIGURATION .....	4-3
REGIONS .....	4-5
Banner Region .....	4-5
Menu Region .....	4-5
Parameter Region .....	4-6
Options Region .....	4-6
DEVICE CONFIGURATION SCREEN .....	4-6
COMMUNICATION STATUS .....	4-7
T1 Network Status .....	4-7
Remote Configuration Mode .....	4-7
DEVICE CONFIGURATION OPTIONS .....	4-7
LOCAL SOFTWARE OPTIONS .....	4-7
<System> .....	4-8
Reset .....	4-8
Port 1 / Port 2 .....	4-8
Port Type .....	4-8
DS0 Rate .....	4-9
Transmit Clock Source .....	4-9
Transmit Clock Polarity .....	4-9
Receive Clock Polarity .....	4-10
Remote Loopback Operation.....	4-10

CTS Mode .....	4-10
RLSD Mode .....	4-10
DSR Mode .....	4-11
TM Mode .....	4-11
LL Mode .....	4-11
RL Mode .....	4-12
DSX-1 Framing .....	4-12
DSX-1 Zero Coding .....	4-12
DSX-1 Line Length .....	4-12
DSX-1 Signaling .....	4-13
DSX-1 Yellow Alarm .....	4-13
DSX-1 Idle Code .....	4-13
NETWORK .....	4-14
Framing .....	4-15
Zero Coding .....	4-15
Timing Source .....	4-15
Line Build-Out .....	4-16
Error History .....	4-17
Yellow Alarm .....	4-17
Line Loopback .....	4-17
Payload Loopback .....	4-18
Idle Code .....	4-18
Port 1 Map / Port 2 Map .....	4-18
TEST .....	4-18
Network Loopback .....	4-19
Network Receive Level .....	4-24
Port Loopback .....	4-24
Port Test Pattern .....	4-28
Port Error Count .....	4-29
Port Test Time .....	4-29
Port Error Ratio .....	4-29
Port Count Reset .....	4-29
ALARMS .....	4-29
Reset Priority .....	4-30
LOS Priority .....	4-30
OOF Priority .....	4-30
AIS Priority .....	4-30

*Table of Contents*

---

YEL Priority .....	4-30
HISTORY .....	4-31
Summary .....	4-31
Errored Seconds.....	4-32
Bursty Errored Seconds .....	4-32
Severely Errored Seconds.....	4-32
Unavailable Seconds.....	4-32
Controlled Slip Seconds .....	4-32
Loss of Frame Count .....	4-32
Main .....	4-32
<Device> .....	4-32
REMOTE SOFTWARE OPTIONS .....	4-33
<System> .....	4-34
Reset .....	4-34
Port 1 / Port 2 .....	4-34
Retrieve Remote Port 1 / Port 2 .....	4-34
NETWORK .....	4-35
TEST .....	4-36
HISTORY .....	4-37
Status .....	4-38
<b>Chapter 5 Local Area Network Operation</b>	
GENERAL .....	5-1
PIGGYBACK CONFIGURATION .....	5-1
PIGGYBACK INDICATORS .....	5-1
NETWORK OPERATION .....	5-1
<b>Chapter 6 Troubleshooting</b>	
GENERAL .....	6-1
COMMON QUESTIONS AND ANSWERS .....	6-2
BEFORE YOU CONTACT MOTOROLA .....	6-4

<b>Appendix A Specifications</b>	
MECHANICAL .....	A-1
ENVIRONMENTAL .....	A-1
T1 INTERFACE CARD .....	A-1
T1 PROTOCOL .....	A-2
DTE INTERFACE .....	A-3
CONFIGURATION MANAGEMENT CARD .....	A-4
POWER REQUIREMENTS .....	A-4
<b>Appendix B Interfaces</b>	
GENERAL .....	B-1
<b>Appendix C Downloading Upgrades</b>	
GENERAL .....	C-1
SETUP .....	C-1
<b>Appendix D T1 Overview</b>	
GENERAL .....	D-1
FRAMING FORMATS .....	D-2
ESF Framing .....	D-4
Framing Format Conversion .....	D-6
PERFORMANCE MONITORING .....	D-6
<b>Appendix E Alarms and Traps</b>	
GENERAL .....	E-1
STATE VARIABLE .....	E-1
ALARM .....	E-1
ALARMTIME .....	E-1
ALARMGATE .....	E-2
<b>Glossary</b>	
<b>Index</b>	
<b>Service and Support</b>	

## List of Illustrations

### Chapter 1 Introduction

1-1	Front Panel.....	1-4
1-2	Rear Panel.....	1-4

### Chapter 2 Installation and Startup

2-1	LAN Management Using Telnet/VT100 Communication.....	2-3
2-2	SNMP Communication.....	2-3
2-3	Typical Cabling.....	2-4
2-4	Front Panel Removal.....	2-5
2-5	Card Removal.....	2-7

### Chapter 3 Configuration Management Card

3-1	Configuration Management Card Switch and Strap Locations.....	3-1
3-2	MGT Port Interface Strap Settings.....	3-4
3-3	Chassis/Digital Ground Strap Settings.....	3-5
3-4	System Screen.....	3-7
3-5	Data Entry in the Parameter Region.....	3-8
3-6	Address/ID Menu.....	3-11
3-7	Time/Date Menu.....	3-11
3-8	Terminal Port Configuration Screen.....	3-12
3-9	Password Security Screen.....	3-13
3-10	Password Security Enabled.....	3-13
3-11	Alarm History.....	3-14
3-12	Alarm Destination Menu.....	3-15

### Chapter 4 T1 Interface Card

4-1	T1 Interface Card.....	4-2
4-2	Device Configuration Screen.....	4-4
4-3	Changing Menu Item Values.....	4-5
4-4	Device Configuration Screen.....	4-6
4-5	Local Main Menus.....	4-8
4-6	Local Network Configuration.....	4-14
4-7	Local Test Menu.....	4-19
4-8	Network Loop 3 (Local).....	4-21

4-9	Network Loop 4 (Line) .....	4-22
4-10	Network Loop 5 (Remote Line).....	4-23
4-11	Port Loop 1 (Local Terminal) .....	4-25
4-12	Port Loop 2 (Remote Terminal).....	4-26
4-13	Port Loop 6 (Remote).....	4-27
4-14	Port Test Pattern Test .....	4-28
4-15	Local Alarms Menu.....	4-30
4-16	Local Summary Menu .....	4-31
4-17	Remote Main Menus .....	4-33
4-18	Remote Network Configuration .....	4-35
4-19	Remote Test Menu .....	4-36
4-20	Remote History Menu .....	4-38
 <b>Chapter 5 Local Area Network Operation</b>		
5-1	Piggyback LEDs for Debugging .....	5-2
 <b>Appendix D T1 Overview</b>		
D-1	Superframe Format.....	D-3
D-2	Extended Superframe Format.....	D-5

## **List of Tables**

### **Chapter 3 Configuration Management Card**

3-1	S29 Dip Switch Options .....	3-3
-----	------------------------------	-----

### **Chapter 4 T1 Interface Card**

4-1	Factory Settings for the Interface Adapter Card .....	4-1
-----	--	-----

### **Appendix B Interfaces**

B-1	T1 Network Connector Pin Functions .....	B-1
B-2	V.35 Pin Functions .....	B-2
B-3	RS-530/449 Pin Functions .....	B-3
B-4	RS-232 Connector Pin Functions .....	B-4
B-5	DSX-1 Connector Pin Functions .....	B-5

### **Appendix D T1 Overview**

D-1	PCM T-Carrier Hierarchy .....	D-1
-----	-------------------------------	-----